


Tabela doborowa magazynów HV SolaX Power	T30 	T58 	HS50 	HS25 HS36 	HS51 	HR76 	HR140 
X1-Hybrid G4 X1-FIT G4	1-4	1-3		2-8	2-8		
X3-Hybrid G4 X3-FIT G4	2-4	2-4	2-6 HS50E-D	3-13	3-13		
X3-Hybrid G4 Pro	2x 2-4	2x 2-4	2x 2-6 HS50E-D	2x 3-13	2x 3-13		
X3-Ultra	2x 2-4	2x 2-4		2x 3-13	2x 3-13		
X3-Aelio					2x 5-13	w opracowaniu	2x 7-14
X1-IES / X3-IES			1-4 / 2-6 HS50E				Kompatybilność może ulec zmianie, stan na 1.09.2025, najnowsze wersje oprogramowania